

# **SpiceExplorer and WaveView Analyzer Installation Guide**

---

Version C-2009.03, March 2009, Rev. A

**SYNOPSYS®**

# Copyright Notice and Proprietary Information

Copyright © 2009 Synopsys, Inc. All rights reserved. This software and documentation contain confidential and proprietary information that is the property of Synopsys, Inc. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Synopsys, Inc., or as expressly provided by the license agreement.

## Right to Copy Documentation

The license agreement with Synopsys permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any. Licensee must assign sequential numbers to all copies. These copies shall contain the following legend on the cover page:

“This document is duplicated with the permission of Synopsys, Inc., for the exclusive use of \_\_\_\_\_ and its employees. This is copy number \_\_\_\_\_.”

## Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

## Disclaimer

SYNOPSIS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

## Registered Trademarks (®)

Synopsys, AMPS, Astro, Behavior Extracting Synthesis Technology, Cadabra, CATS, Certify, Design Compiler, DesignWare, Formality, HDL Analyst, HSIM, HSPICE, Identify, iN-Phase, Leda, MAST, ModelTools, NanoSim, OpenVera, PathMill, Physical Compiler, PrimeTime, SCOPE, Simply Better Results, SiVL, SNUG, SolvNet, Syndicated, Synplicity, the Synplicity logo, Synplify, Synplify Pro, Synthesis Constraints Optimization Environment, TetraMAX, VCS, Vera, and YIELDirector are registered trademarks of Synopsys, Inc.

## Trademarks (™)

AFGen, Apollo, Astro-Rail, Astro-Xtalk, Aurora, AvanWaves, BEST, Columbia, Columbia-CE, Confirma, Cosmos, CosmosLE, CosmosScope, CRITIC, DC Expert, DC Professional, DC Ultra, Design Analyzer, Design Vision, DesignerHDL, DesignPower, Direct Silicon Access, Discovery, Eclipse, Encore, EPIC, Galaxy, Galaxy Custom Designer, HANEX, HAPS, HapsTrak, HDL Compiler, Hercules, Hierarchical Optimization Technology, High-performance ASIC Prototyping System, HSIM<sup>plus</sup>, i-Virtual Stepper, IICE, in-Sync, iN-Tandem, Jupiter, Jupiter-DP, JupiterXT, JupiterXT-ASIC, Liberty, Libra-Passport, Library Compiler, Magellan, Mars, Mars-Rail, Mars-Xtalk, Milkyway, ModelSource, Module Compiler, MultiPoint, Physical Analyst, Planet, Planet-PL, Polaris, Power Compiler, Raphael, Saturn, Scirocco, Scirocco-i, Star-RCXT, Star-SimXT, System Compiler, System Designer, Taurus, TotalRecall, TSUPREM-4, VCS Express, VCSi, VHDL Compiler, VirSim, and VMC are trademarks of Synopsys, Inc.

## Service Marks (sm)

MAP-in, SVP Café, and TAP-in are service marks of Synopsys, Inc.

SystemC is a trademark of the Open SystemC Initiative and is used under license.

ARM and AMBA are registered trademarks of ARM Limited.

Saber is a registered trademark of SabreMark Limited Partnership and is used under license.

All other product or company names may be trademarks of their respective owners.

Printed in the U.S.A.

SpiceExplorer and WaveView Analyzer Installation Guide, C-2009.03

# Installing SpiceExplorer and WaveView Analyzer

---

This document describes how to install the SpiceExplorer and WaveView Analyzer product.

**Note:**

The installation instructions in this document are the most up-to-date available at the time of production. However, changes might have occurred. For the latest installation information, see the product release notes or documentation.

This document provides instructions for the UNIX, Linux, and Windows platforms. The document includes the following sections:

- [Preparing for Installation](#)
- [Installing SpiceExplorer and WaveView Analyzer \(UNIX and Windows\)](#)
- [Invoking SpiceExplorer and WaveView Analyzer on Windows](#)
- [Installing the SX-CDS Link Package](#)
- [Installing the SX-DAIC Link Package](#)
- [Installing the SX-VSDE Link Package](#)
- [Viewing and Printing SpiceExplorer and WaveView Analyzer Documentation in Portable Document Format \(PDF\)](#)
- [Troubleshooting SpiceExplorer and WaveView Analyzer Installation on Solaris Platforms](#)
- [Uninstalling SpiceExplorer and WaveView Analyzer](#)
- [Customer Support](#)

**Important:**

Do not install later versions of the SpiceExplorer and WaveView Analyzer tools over earlier versions of the tools.

## Preparing for Installation

Before beginning the installation process, read the *SpiceExplorer and WaveView Analyzer Release Notes*. The release notes are in Portable Document Format (PDF) and are located in the electronic software transfer (EST) download directory. They require a PDF file reader to view and print them. Check for the following information:

- Changes in licensing requirements
- Changes in memory requirements
- The operating system versions on which the software is supported
- Changes made from prior releases

If you have not already done so, retrieve your license keys from the SmartKeys Web page at <http://solvnet.synopsys.com/smartkeys>.

For detailed licensing information, see the Synopsys Licensing QuickStart Guide Web page at <http://www.synopsys.com/keys>.

*UNIX:* Root or administration privileges are not required.

*Windows:* Administration privileges are required for installing and uninstalling the tool. To ensure a successful installation, confirm that previous releases have been uninstalled (see *Installing Synopsys Tools*, available at <http://www.synopsys.com/install/>). If licensing will be installed with this installation, you must stop any existing license servers (Imgrd or avantd), then uninstall licensing. To stop the avantd FLEXIm license server or FLEXIm license server, choose **Administrative Tools > Services** from the Control Panel.

---

## Supported Platforms and Compilers

SpiceExplorer and WaveView Analyzer is available on CD or by EST. Obtain the appropriate binary executable files for your operating system. Table 1 lists the supported platforms for this release.

*Table 1 Supported Platforms, Operating Systems, and Keywords*

<b>Platform</b>	<b>Operating system</b>	<b>Synopsys platform keyword</b>	<b>Window environment</b>
Sun SPARC	Solaris 9 (32-bit and 64-bit)	sparcOS5	CDE
IA-32 (X86) AMD Opteron (64-bit)	Red Hat Enterprise Linux v4	linux (32-bit mode) linux (64-bit mode)	GNOME
IA-32 (X86)	XP Professional v2002	winXP	
IA-32 (X86)	Windows 2000/ME/NT	win2000, winme, winnt	
IA-32 (X86)	Windows 95/98	win95, win98	

## **Disk Space and Memory Requirements**

The disk space requirement varies depending on the platform and the features selected for installation. Table 2 shows the maximum space required for installing all SpiceExplorer and WaveView Analyzer features on a particular platform. Each CD also includes this information in the top-level INSTALL\_README.wri file.

*Table 2 Disk Space and Memory Requirements (in Megabytes)*

<b>Platform</b>	<b>Software (maximum)</b>	<b>Default temporary directory location</b>	<b>Temporary disk space from CD</b>	<b>Temporary disk space from EST</b>
Solaris	83	/var/tmp	83	83
Linux	83	/tmp	83	83
Windows	12	%TEMP% or C:\My Documents\temp	12	12

## Installing SpiceExplorer and WaveView Analyzer

Installing SpiceExplorer and WaveView Analyzer (UNIX and Windows)

---

## Installing SpiceExplorer and WaveView Analyzer (UNIX and Windows)

WaveView Analyzer is released as part of Synopsys SpiceExplorer product suite. The license key determines if the application can be started in the "full SpiceExplorer" mode, the "WaveView Analyzer only" mode, or both. The default startup mode can be configured in the Preference Settings.

You can install SpiceExplorer and WaveView Analyzer using a GUI or by using text commands. By default, the SpiceExplorer and WaveView Analyzer installer invokes the installation GUI. To install SpiceExplorer and WaveView Analyzer using text commands, see [Installing Synopsys Tools](#).

---

## Downloading SpiceExplorer and WaveView Analyzer by EST

Download the following required product files to a temporary directory:

- A platform-independent (common) file, which contains the binaries for the amd64\_re4, i86\_re4, sun4\_u5, sun4\_u5\_64, x86sol\_32, and x86sol\_64 platforms.
- The Synopsys Installer, which includes the scripts for text or GUI installation. (To determine the latest installer version, see [Installing Synopsys Tools](#).) For more information on downloading and configuring the installer, see the installer\_INSTALL\_README.txt file in the rev/installer\_x.y directory, where x.y is the latest version of the installer.

### Note:

The Synopsys Installer is required only for products that have a "common" file. The installer needs to be downloaded only once per release and can be used to install all software with a "common" file.

For example:

This example assumes that you are in the rev directory. If you are in another directory, (rev\_o or auth, for example), replace rev with the appropriate directory.

## Installing SpiceExplorer and WaveView Analyzer

### Installing SpiceExplorer and WaveView Analyzer (UNIX and Windows)

```
# Get the product files

% cd /usr/tmp/tmpdir1
% ftp ftp.synopsys.com
220 Synopsys FTP server ready

Name: <your_synopsys_username>
Password: <your_synopsys_password>
230 User <your_synopsys_username> logged in.

ftp> binary
ftp> cd rev
ftp> cd spiceexplorer_vC-2009.03
ftp> get

      sx_INSTALL_README.txt
      sx_vC-2009.03_common.tar
      checksum_info.txt
```

The checksum\_info.txt file includes the following information:

CRC	size	filename
423335234917305600		product_version_common.tar

You can use the UNIX `cksum` command to validate the integrity of the downloaded files.

For example:

```
UNIX> cksum product_version.common.tar

4233352349      17305600      product_version.common.tar
```

#### Note:

You no longer need to download the EST (or FTP) files for multiple products into a separate temporary directory. For specific product download instructions, see the SolvNet Download Center at <https://solvnet.synopsys.com/DownloadCenter/dc/product.jsp>

The UNIX release directory contains the following files and directories:

File or Directory	Description
LICENSE	License agreement

## Installing SpiceExplorer and WaveView Analyzer

Installing SpiceExplorer and WaveView Analyzer (UNIX and Windows)

File or Directory	Description
bin/	SpiceExplorer/WaveView Analyzer wrapper script
doc/	Documentation
etc/	
include/	Header file and examples for the WDF writer
syntax/	Syntax rules for VIM editors
packages/	
SX-CDS-Link/	CDS-Link package
SX-DAIC-Link/	DAIC-Link package
SX-VSDE-Link/	VSDE-link package
platforms/sun4_u5/	
bin/	32-bit SpiceExplorer executables
lib/	32-bit NanoSim/VPI/WDF-writer libraries
lic/	32-bit Flexlm license management tools
platforms/sun4_u5_64/	
bin/	64-bit SpiceExplorer executables
lib/	64-bit NanoSim/VPI/WDF-writer libraries
lic/	64-bit Flexlm license management tools

The MS Windows version of WaveView Analyzer is distributed in a self-extracting executable file. To install the software on Windows systems, download the file to your PC, and double click the file icon to activate the automated installation sequence.

The automated installation sequence adds WaveView Analyzer entries to the Windows **Start** menu and a shortcut to WaveView Analyzer on the Windows

Desktop. Double click the shortcut, or select the **SpiceExplorer** entry from the **Start** menu to launch a WaveView Analyzer job.

---

## Installing SpiceExplorer and WaveView Analyzer

To install the software:

1. Get the Synopsys Installer (if needed).
2. Add the installer directory to your UNIX path.
3. Enter one of the following installer commands to start the installation:

```
% set path=(/usr/synopsys/installer $path)
```

```
% installer #To use a text script
```

```
% installer -gui (or setup.sh) #To use a GUI
```

If you invoked the installer from either the installer directory or a directory that does not contain product files (such as \$HOME), you are prompted to provide a source path to the temporary directory containing the product files.

If you invoke the installer from the temporary product file directory, you are not asked to provide a source path.

4. Answer the installer prompts.  
When you are prompted to choose a location for installing the software, do not select the temporary directory. You must specify a new location.  
If you are installing multiple operating system platforms, you need to install the platform-independent package only once for each product. The platform-independent package contains files that are common to all the supported platforms.
5. After installation is complete, each user must modify the path, set a licensing variable, and set any product-specific variables.

---

## Installing SpiceExplorer and WaveView Analyzer from a CD

Mounting the CD might require root access privileges. If you do not have root access privileges, see your system administrator for instructions on mounting the CD. For detailed instructions, see [Installing Synopsys Tools](#).

## Setting Up Licenses

### Note:

You must have the SCL daemon version SCL10.9.3 or later to set up your license.

WaveView Analyzer uses Flexlm for license management. If you receive an uncounted node-locked evaluation or demo license, no license server needs to be started.

UNIX Platforms: To install an uncounted node-locked evaluation license, append the full path of the license file (including the license file name) to the `SNPSLMD_LICENSE_FILE` environment variable.

Windows Platforms: To install an uncounted node-locked evaluation license, start the WaveView Analyzer application. Select the **Specify the License File** option, and follow the automated steps to setup the license file. You need to do this only once when you start WaveView Analyzer for the first time.

To install a production or floating license, you need to start the license server by entering the following line:

```
lmgrd -c license.dat
```

The `lmgrd` license server automatically invokes the `snpslmd` vendor daemon. Make sure the path to the `snpslmd` vendor daemon is appended to the `VENDOR` line in your license file. You can find `lmgrd` and `snpslmd` in the `bin/` directory for different platforms. Please consult your system administrator to install the floating license. A copy of Flexlm end user's manual is included in the `doc/` directory. An online user's manual is also available at <http://www.macrovision.com/>.

---

## Invoking SpiceExplorer and WaveView Analyzer on Windows

To invoke SpiceExplorer and WaveView Analyzer on Windows platforms,

1. Start the tool by choosing **Start > Programs > SpiceExplorer *version number***. The SpiceExplorer window opens.
2. To check the product version, choose **Help > About SpiceExplorer**.
3. To exit SpiceExplorer, choose **File > Exit**.

## Installing the SX-CDS Link Package

The SX-CDS Link package requires the "sx\_cdslink" license from Synopsys. The post-layout cross-probing functions require the "sx\_cdslink\_ext" license.

The SX-CDS Link package consists of the following files:

- sx\_link.ile: the encrypted SX-CDS Link SKILL module.
- sx\_menu.il: the SKILL module for SX-CDS tool menu.
- sx\_user.il: the user-customizable SKILL module.
- schematic.menus: the menu file for the Composer integration.
- simui.menus: the menu file for the Virtuoso ADE integration.

Synopsys SX-CDS Link supports schematic to viewer cross probing in two different Cadence schematic entry environments:

1. Virtuoso Analog Environment mode: Also referred to as the Analog Artist mode involving integrated ADE window, Parametric analysis window, Composer, calculator, and waveform viewer.
2. Composer-only mode: Uses only the Composer schematic entry tool without the ADE environment. If the Cadence "SE" (Simulation Environment) is available, simulation jobs can be launched from the simulator menu in Composer. If the "SE" option is not available, users usually run simulation manually in an outside shell window.

Depending on your Cadence working environment, the SX-CDS Link package can be installed using two different methods. The following table summarizes the needed components for each installation method.

*Table 3 SX-CDS Link Installation Components*

	Method 1: Trigger Function		Method 2: Menu File	
	Composer	ADE Mode	Composer	ADE Mode
sx_link.ile	X	X	X	X
sx_menu.il	X	X		
sx_user.il	optional	not needed	optional	not needed
simui.menus				X

*Table 3 SX-CDS Link Installation Components*

Method 1: Trigger Function		Method 2: Menu File	
Composer	ADE Mode	Composer	ADE Mode
schematic.menus		X	

## Installation Method 1: User Trigger Function

This is the preferred installation method for SX-CDS Link. The following files from the SX-CDS Link package: `sx_link.ile`, `sx_menu.il`, and `sx_user.il` are required. The `sx_user.il` SKILL file is required only if you want to customize the SX-CDS Link for the Cadence SE integration. The two menu files, `schematic.menus` and `simui.menus`, are not required.

**Advantage:** No root authority is needed to install the package. A single installation works for both the "Virtuoso ADE" and the "Composer-only" mode. SX-CDS Link tool menu is automatically updated when users switch between the "Virtuoso ADE" and the "Composer-only" mode.

**Disadvantage:** The SX-CDS Link tool menu always appears in the Composer schematic window. The menu cannot be inserted into the top tool menu of the "Artist Design Environment (ADE)" window. If you prefer to add the SX-CDS menu to the ADE window, you will have to install SX-CDS Link using the menu file `simui.menus`. (See the next section)

Follow the steps below to install the SX-CDS Link package:

1. Add the following `load` commands to your `.cdsinit` file:

```
load("/path_to/sx_link.ile" "sandwork")
load("/path_to/sx_menu.il")
load("/path_to/sx_user.il")
```

The `.cdsinit` file is usually located in your home directory. If the `.cdsinit` file also exists in the working directory, the settings override those in the `.cdsinit` file in the your home directory. Use absolute paths to load the SX-CDS SKILL modules into `.cdsinit`.

2. Enter `which sx` in a shell window to verify that `sx` is located in your search path. If `sx` cannot be found in your search path, you need to append the path to the `sx` executable in the `path` (or `PATH`) variable in your shell init file. For example:

```
set path=( $path /directory_path_to_sx )
```

3. If you have already used the SKILL user trigger function to customize the menu for other applications in the Cadence Composer schematic entry tool, you might need to manually merge the SX-CDS trigger functions with your existing user trigger functions. The user trigger registration functions for SX-CDS Link can be found in the `sx_menu.il` text SKILL module.

---

## Installation Method 2: Menu Files

This method requires the use of the `schematic.menus` and `simui.menus` menu files to add the SX-CDS Link tool menu to the Cadence tools. The `sx_link.ile` SKILL module (and `sx_user.il` module, if you want to customize the SX-CDS Link for SE integration), are also required. The `sx_menu.il` SKILL module is not required.

### Note:

The two menu files cannot co-exist in the menu file directory. You can only select one menu file to install: either `schematic.menus` or `simui.menus`.

Advantage: The SX-CDS Link menu can be inserted into the top menu bar of the ADE window in the "Virtuoso ADE" mode.

Disadvantages: The "Composer-only" and the "Virtuoso ADE" mode cannot co-exist in one DFII environment. Users need re-installation to switch between the "Composer-only" and the "Virtuoso ADE" mode. Root authority is usually needed if the menu file is to be installed in the public Cadence tool directory.

## Composer-Only Mode

To install the SX-CDS Link package for the Composer-only mode:

1. Add the following line to your `.cdsinit` file:

```
load("/path_to/sx_link.ile" "snpslmd")
```

2. Copy `schematic.menus` to the following directory:

```
$cadence_install_dir/dfII/local/menus
```

3. Enter `which sx` in a shell window to verify that `sx` is located in your search path. If `sx` cannot be found in your search path, you need to append the path to the `sx` executable in the `path` (or `PATH`) variable in your shell init file. For example:

## Installing SpiceExplorer and WaveView Analyzer

### Installing the SX-CDS Link Package

```
set path=($path /directory_path_to_sx)
```

The `.cdsinit` file is usually located in your home directory. If `.cdsinit` also exists in the working directory, the settings override those in the `.cdsinit` file in the your home directory. Use absolute paths to load the SX-CDS SKILL modules into `.cdsinit`.

If you have an existing `schematic.menu` menu definition file under the `$cadence_install_dir/dfII/local/menus` directory, you might need to merge the content from the provided `schematic.menu` menu definition into the existing `schematic.menu` menu file.

To limit the installation to your private working environment without changing your Cadence site setup, move the `menus/schematic.menu` directory to your home directory. Create a directory named `menus` under your home directory if necessary.

SX-CDS link is developed based on DFII 4.4.6. Minor modifications of `schematic.menu` might be required for integration into earlier versions of DFII. For example, the Composer program in DFII version 4.4.3 does have the **Option** top menu entry. As a result, the `schSOptionPulldown` entry that is near the end of `schematic.menu` needs to be commented out with leading semi-colons (;).

## Virtuoso ADE Mode

To install the SX-CDS Link package for the Virtuoso ADE mode:

1. Add the following line to your `.cdsinit` file:

```
load("/path_to/sx_link.file" "snpslmd")
```

2. Copy `simui.menu` to the following directory:

```
$cadence_install_dir/dfII/local/menus
```

3. Enter `which sx` in a shell window to verify that `sx` is located in your search path. If `sx` cannot be found in your search path, you need to append the path to the `sx` executable in the `path` (or `PATH`) variable in your shell init file. For example:

```
set path=($path /directory_path_to_sx)
```

The `.cdsinit` file is usually located in your home directory. If `.cdsinit` also exists in the working directory, the settings override those in the `.cdsinit` file in the your home directory. Use absolute paths to load the SX-CDS SKILL modules into `.cdsinit`.

If you have an existing `simui.menu` menu definition file under the `$cadence_install_dir/dfII/local/menus/` directory, you might need to merge the content from the provided `simui.menu` menu definition into the existing `simui.menu` menu file.

To limit the installation to your own working environment without changing your Cadence site setup, move `menus/simui.menu` to your home directory. Create the `menus` directory under your home directory if necessary.

---

## Special Note for IC5141 USR3 (or later) Users

In the Cadence IC5141 USR3 release, the default output format of Spectre and `spectreVerilog` was changed from PSF/WSF to SST2. Since WaveView Analyzer does not support the Cadence SST2 format, the following configuration is required to restore the default format to PSF:

- Spectre: Add the following line to your `$HOME/.cdsenv` file:  

```
spectre.envOpts simOutputFormat string "psfbin"
```
- UltraSim: From the ADE window go to [Simulation - Options - Analog] and select PSF as the output format.
- `spectreVerilog`: Add the following lines to your `$HOME/.cdsenv` file:  

```
spectreVerilog.envOpts simOutputFormat string "psfbin"  
spectreVerilog.envOpts logicOutputFormat string "WSF"
```
- UltraSimVerilog: From the ADE window, choose **Simulation > Options > Analog**, and select PSF as the output format. Then, add the following line to your `$HOME/.cdsenv` file:  

```
UltraSimVerilog.envOpts logicOutputFormat string "WSF"
```

---

## SX-CDS Link for AMS Designer

SX-CDS Link supports cross-probing in AMS Designer only with the Synopsys WDF format. The following line must be added to the `$HOME/.cdsenv` file:

```
ams.envOpts simOutputFormat string "wdf"
```

When the WDF format is used with AMS Designer, the simulation results are stored in two files under the `psf/` directory: (1) `ams_database.vcd` for logic waveforms from `ncsim`, and (2) `tran.tran.wdf` or `amsControl.-1.wdf` for analog waveforms from Spectre or UltraSim. SX-CDS link looks for these output files automatically if "ams" is selected as the simulator in Virtuoso.

## Installing the SX-DAIC Link Package

The SX-DAIC Link package requires the "sx\_daiclink" license.

The installation processes differ depending on the DAIC release version that you are using. Choose one of the following installation processes:

- [Installing SX-DAIC Link for DAIC Version 2002.2 and Earlier](#)
- [Installing SX-DAIC Link for DAIC Versions 2002.3 through 2003.4](#)
- [Installing SX-DAIC Link for DAIC Versions 2004.1 and Later](#)

---

### Installing SX-DAIC Link for DAIC Version 2002.2 and Earlier

WaveView Analyzer utilizes AMPLE functions in schematic.ample to communicate with DAIC. The provided schematic.ample AMPLE module contains a modified version of the AMPLE functions from the original install tree, which is located here:

```
$MGC_HOME/shared/pkgs/daicsim/userware/default/  
schematic.ample
```

If the same AMPLE functions are already modified in your setup, you need to manually merge the changes. Please refer to the comment or documentation in the provided schematic.ample file for details.

To install the SX-DAIC Link package:

1. Copy the WaveView Analyzer executable (sx) to the \$MGC\_HOME/bin directory. If you prefer to place the executable in a different location, please modify the initial value of the sx\_command\_default AMPLE variable in schematic.ample.
2. You can merge the provided schematic.ample into the following public file, or keep the provided schematic.ample file in a non-public directory (the user AMPLE directory):

```
$MGC_HOME/shared/pkgs/daicsim/userware/default/  
schematic.ample
```

3. Modify the AMPLE\_PATH variable to include the directory, and copy schematic.ample to \$AMPLE\_PATH/da\_ic.

## Installing SX-DAIC Link for DAIC Versions 2002.3 through 2003.4

WaveView Analyzer utilizes AMPLE functions in `schematic_sim.ample` and `daic_sim_mgr.ample` to communicate with DAIC. The provided `schematic_sim.ample` and `daic_sim_mgr.ample` AMPLE modules contain modified versions of the AMPLE functions necessary for the cross-probing integration. The original AMPLE modules are located in the install tree here:

```
$MGC_HOME/shared/pkgs/da_ic/userware/default
```

If the same AMPLE functions are already modified in your setup, you need to manually merge the changes. Please refer to the comment or documentation in the AMPLE modules file for details.

To install the SX-DAIC Link package:

1. Copy the WaveView Analyzer executable (`sx`) to the `$MGC_HOME/bin` directory. If you prefer to place the executable in a different location, please modify the initial value of the `sx_command_default` AMPLE variable in `schematic_sim.ample`.
2. You can merge the provided AMPLE modules into the following public directory, or keep the provided modules in a non-public directory (the user AMPLE directory):

```
$MGC_HOME/shared/pkgs/da_ic/userware/default/
```

3. Modify the `AMPLE_PATH` variable to include the private AMPLE directory, and copy `schematic_sim.ample` and `daic_sim_mgr.ample` to `$AMPLE_PATH/da_ic`.

---

## Installing SX-DAIC Link for DAIC Versions 2004.1 and Later

The installation steps are the same as those for [Installing SX-DAIC Link for DAIC Versions 2002.3 through 2003.4](#), except that the `daic_sim_mgr.ample.2004.1` and `schematic_sim.ample.2004.1` AMPLE codes are used instead.

---

## Installing the SX-VSDE Link Package

The SX-VSDE Link package requires the SpiceExplorer-Cadence Link "sx\_cdslink" license.

## Installing SpiceExplorer and WaveView Analyzer

Viewing and Printing SpiceExplorer and WaveView Analyzer Documentation in Portable Document Format (PDF)

To install the SX-VSDE package:

1. Copy the waveform.cfg file to the `$ACV_ROOT/admin` directory. If waveform.cfg already exists in `$ACV_ROOT/admin`, append the content from the included waveform.cfg file to the existing one.
2. Copy `sx_run` to the `$ACV_ROOT/bin` directory.
3. Modify the path of the WaveView Analyzer executable in the `sx_run` file.

---

## Viewing and Printing SpiceExplorer and WaveView Analyzer Documentation in Portable Document Format (PDF)

To view and print SpiceExplorer and WaveView Analyzer documentation in Portable Document Format (PDF), you must have Adobe Acrobat Reader installed on your machine. To determine which version of Adobe your operating system requires, see Table 4.

Table 4 shows which version of Adobe Reader you need to use with a particular release.

*Table 4 Platform and Supported Version*

Platform	Product documentation version	Adobe Reader version
Linux	A-2008.03 or later	Adobe Reader 7.0
Sun SPARC (Solaris) <sup>1</sup>	A-2008.03 or later	Adobe Reader 7.0
Windows	A-2008.03 or later	Adobe Reader 6.0 or 7.0

*1. On Solaris operating systems, the GNOME desktop manager must be installed to support Adobe Reader 7.0.*

---

## Troubleshooting SpiceExplorer and WaveView Analyzer Installation on Solaris Platforms

If you encounter the following error message while running SpiceExplorer:

```
ld.so.1: ./sx: fatal: libXm.so.3: can't open file: errno=2  
Killed
```

Append `/usr/dt/lib` to your `LD_LIBRARY_PATH` environment variable. For example:

```
setenv LD_LIBRARY_PATH /usr/dt/lib:$LD_LIBRARY_PATH
```

By default, the CDE window manager environment allows popup dialog windows to appear behind the main application window. This default setting can make it difficult to locate a dialog window that is hidden behind the main window. To change the default setting, choose **Style Manager > Window**, and deselect the "Allow Primary Windows On Top" option. The **Style Manager** can be started from the **Tools** menu.

---

## Uninstalling SpiceExplorer and WaveView Analyzer

To uninstall SpiceExplorer and WaveView Analyzer on UNIX, delete the entire software installation directory.

To uninstall the SpiceExplorer and WaveView Analyzer on Windows, go to **My Computer > Control Panel > Add/Remove Programs**, select **SpiceExplorer** from the list, and click the **Add/Remove** button to uninstall.

The uninstall operation varies slightly on other Windows O/S (Windows 2000/XP/ME/NT). Please follow the standard application removal procedure in each Windows environment to remove SpiceExplorer.

---

## Customer Support

For information about accessing customer support, see [Installing Synopsys Tools](#).

**Installing SpiceExplorer and WaveView Analyzer**  
Customer Support