

IC Compiler Installation Notes

Version C-2009.06

June 8, 2009

These installation notes present information about installing IC Compiler version C-2009.06 in the following sections:

- [Media Availability and Supported Platforms](#)
- [Disk Space and Memory Requirements](#)
- [Installing the Software](#)
- [Setting Up the User Environment](#)
- [Verifying the IC Compiler Installation](#)

Note:

The installation instructions in this chapter are the most up-to-date available at the time of production. However, changes might have occurred. For the latest installation information, see the product release notes or documentation.

See also <http://www.synopsys.com/Support/Licensing/Installation/Pages/default.aspx> for additional installation and licensing information.

Media Availability and Supported Platforms

IC Compiler is available by EST download upon initial software release, and at a later date on DVD (or CD depending on image size).

[Table 1](#) shows the supported compute platforms, operating systems, Synopsys platform keywords, and windowing environments for this release.

Table 1 Supported Platforms, Operating Systems, and Keywords

Compute Platform	Operating System	Synopsys Platform Keyword	Windowing Environment
x86_64	Red Hat Enterprise Linux v4, 5 ¹	amd64 (64-bit mode) linux (32-bit mode) ²	GNOME
x86_64	SUSE Enterprise Linux v9, 10 ¹	suse64 (64-bit mode) suse32 (32-bit mode)	KDE
x86_64	Solaris 10	x86sol64 (64-bit mode)	CDE
x86	Red Hat Enterprise Linux v4, 5 ¹	linux (32-bit mode) ²	GNOME
x86	SUSE Enterprise Linux v9,10 ¹	suse32 (32-bit mode)	KDE
Sun SPARC	Solaris 9, 10 ¹	sparc64 (64-bit mode)	CDE

1. Binary-compatible hardware platform or operating system. Note, however, that binary compatibility is not guaranteed. See <http://www.synopsys.com/Support/Licensing/Pages/default.aspx> for latest information.

2. The 32-bit (x86) and 64-bit (x86_64) Linux software is binary compatible with the Intel EM64T or AMD Opteron running Red Hat Enterprise Linux. See <http://www.synopsys.com/Support/Licensing/Pages/default.aspx> for latest information.

Disk Space and Memory Requirements

The disk space requirement depends on the platform. [Table 2](#) shows the maximum space required for installing IC Compiler on a particular platform.

Table 2 Disk Space Requirements (in Megabytes)

Operating System	Megabytes
Red Hat Enterprise, Linux v4, 5	1120
SUSE Enterprise, Linux 9, 10	1090
Solaris 9, 10	1340

The minimum physical memory required is 150 MB. The recommended minimum physical memory is 1 GB. The minimum swap space is 256 MB. The recommended minimum swap space is 2 GB. For large designs, the expected amount of required memory is approximately 1 million bytes per 2,000 gates.

Accessing Memory Beyond 2 GB With 32-Bit Tools

The IC Compiler tool can extend memory beyond 2 GB. Note that available memory is calculated as space not used by the operating system (OS), the windowing system, or other applications.

To access memory beyond 2 GB,

1. Make sure your server has at least 4 GB of memory (physical and swap space) available.

Note:

Physical memory equals data size plus stack size and stack size is used before data size. Therefore, setting stack size to a large value causes problems for designs that are larger than 2 GB. If you set the stack size too high, you cannot get enough memory for your data. To check the settings, use the `limit` command at the system prompt.

2. Make sure the system you are using does not have restrictions that prevent you from using more than 2 GB of memory.

3. Create unlimited data size using the C, Bourne, Korn, or Bash shell. If there are system-wide limits on the data size you can create, you can remove them or override them.

- Enter one of the following commands based on the shell you are using:

For the C shell,

```
% limit datasize 3800000
```

For the Bourne, Korn, or Bash shell,

```
# ulimit -s -d 3800000
```

- Modify the kernel of your server. This approach allows everyone using your server to extend memory beyond 2 GB.

Installing the Software

IC Compiler uses the Synopsys Installer tool, which allows you to use a text script or a graphical user interface (GUI). For information about downloading the Synopsys Installer, see *Installing Synopsys Tools* at <http://www.synopsys.com/Support/Licensing/Installation/Pages/default.aspx>.

To install IC Compiler, follow the procedures described in *Installing Synopsys Tools*. This document provides a Synopsys media installation script. IC Compiler is installed in a similar manner.

IC Compiler is a stand-alone product and cannot be installed over an existing Synopsys product, including a prior versions of IC Compiler. You must create a new directory for IC Compiler.

Setting Up the User Environment

To set up the user environment, you must specify the location of the executable file and set the license environment variable.

Specifying the Executable File Location

A platform-independent wrapper script is provided for IC Compiler. This script automatically determines the operating system platform at runtime, which simplifies the setup required to use IC Compiler.

The platform-independent wrapper script is located at *install_dir*/bin and include the following options:

```
-32bit | -64bit
```

Note:

If you select a platform executable file that is not available, you are automatically switched to an available platform based on your current environment. No warning message is issued.

To set up the environment by using the platform-independent wrapper script, add the IC Compiler bin directory to the `PATH` environment variable.

If you are using the C shell, add the following line to the `.cshrc` file:

```
set path=(install_dir/bin $path)
```

If you are using the Bourne, Korn, or Bash shell, add the following line to the `.profile`, `.kshrc`, or `.bashrc` file:

```
PATH=install_dir/bin:$PATH  
export PATH
```

Replace *install_dir* with the IC Compiler installation directory.

Setting the SNPSLMD_LICENSE_FILE Environment Variable

You must install the Synopsys Common Licensing (SCL) software and define the `SNPSLMD_LICENSE_FILE` variable before you can verify the IC Compiler installation.

For information about downloading SCL, installing SCL, or setting the license variable, see *Installing Synopsys Tools* at <http://www.synopsys.com/Support/Licensing/Installation/Pages/default.aspx>.

Configuring the Browser for Online Help

The online Help system is a browser-based HTML Help system designed for viewing in Firefox and Mozilla Web browsers. You can use any of the following browsers:

- Firefox 2.0 or 1.5
- Mozilla 1.7

If you prefer to use other browsers, note the following limitations:

- Online Help does not work in Netscape version 6.0.
- Online Help might work in Netscape versions 4.7x, 4.8, and 7.0, or in other browsers such as Internet Explorer or Opera, but is it not tested or supported in these browsers.

Important:

When you use online Help from within the GUI, the directory containing the browser executable file must be in the search path specified by your UNIX or Linux `$PATH` variable.

The default browser is Firefox. To use a different browser, change the `gui_online_browser` variable in your `.synopsys_icc_gui.tcl` setup file. You can also change the browser for the current session by setting this variable from within the GUI. For example,

```
icc_shell> set gui_online_browser "mozilla"
```

The choices are `firefox` or `mozilla`.

Verifying the IC Compiler Installation

To verify the IC Compiler Installation, make sure you are in a directory where you have read/write privileges.

```
% cd $HOME
```

Invoke the tool by entering one of the following commands on a licensed machine.

If you are in GUI mode, enter

```
% install_dir/platform/syn/bin/icc_shell -gui
```

If you are in shell mode, enter

```
% install_dir/platform/syn/bin/icc_shell
```

Replace *install_dir* with the IC Compiler installation directory and platform with the appropriate platform (see [Table 1](#)).

If you see information about the product version, production date, and copyright, the installation was successful.